

If digital Hymer display is showing good voltages but not showing the correct battery % charged.

The message below was from Udo Lang at Schaudt Germany.

Please set the display panel to the correct Ah of your batteries.

Then charge the battery for 24 hours on the mains.

Disconnect from the mains and drain the battery for 1 hour with a minimum of -10A.

Then connect the mains again.

The battery should go up in the voltage level to 14,3V and will end at 13.8V float-charging.

The Ah's should be shown with max capacity i.e $250\text{Ah}/100\% \times 80\% = 200\text{Ah} = 100\%$ fully charged..

Best Regards

Udo.